



SUPER SPORT - FENDER SECURE BOLT

Kit: 4 x M6 x 25 c/sunk Allenhead screw (304 SS)
4 x M6 Nyloc nut

Tools: 10mm wrench
4mm hex key wrench

- One bolt per fender, on the back end of each lifting arm.
- Tighten so the countersunk head of the bolt recesses into the fender backing plate.
- Note: If the hole is not through the plastic inner fender, drill through with an 8mm drill bit.

We strongly recommend you install one bolt per fender and let the customer know if they want a removable fender for extra low car then remove the retaining bolt and rely on the button latches.

When button latches alone are relied on to hold the fender the owner **MUST** check the latches are secure before towing.



ENGINEERED TO BE EFFORTLESS