



ROCK GUARD INSTALLATION GUIDE

1



TOOLS NEEDED:

Torque wrench (3/8" drive)
5mm hex bit socket
6mm hex bit socket
Anti-seize compound

Place Rock Guard in position on the front of the trailer deck.

2



Attach 2 M8x80-90SS-BHS Washers & Nylocks.

Apply anti-seize on the bolts.

The Rock Guard comes supplied with all M10 Bolts.

RECOMMENDED TORQUE SETTINGS

M10 Bolts: 24 Nm (18 lb-ft)

M8 = 12 Nm (9 lb-ft)

3



Install the supplied M10 Bolts with Washer & Nylock Nut along the front of the Rock Guard.

The center bolt is reversed from the inside.