




FITTING INSULATION CARD - INSTRUCTIONS.

TO DOUBLE THE INSULATION BETWEEN THE WINCH TERMINAL AND THE WINCH BOX.



Place the plastic insulation card in the winch box above the winch electrical terminal. Slide the card down between the terminal and the back of the winch box.



IF THE CARD DOES NOT SLIDE IN PLACE

Insert wrench, flat head screw driver or small pry bar and pull back to press out the back of the winch box slightly - press the card down at the same time. It doesn't require a lot of pressure to press the back of the winch box away from the winch and allow the card to fit in place.



The card drops into place, between the terminal and the back of the winch box.

If the card falls out then there is no issue as there is a gap between the terminal and the winch box. What we are trying to achieve in placing the insulation card is an additional insulating layer between the winch terminal and the winch box.